

Precision Regulator Series IR1000/2000/3000



The addition of the small size Series IR1000 and the large size Series IR3000 provides an increased range of flow rates from approx. 200ℓ/min. to approx. 6000ℓ/min.

Precision Regulator Series IR1000/2000/3000

Bracket and pressure gauge can be mounted from 2 directions

Mounting is possible on either the front or the back

Expanded regulating pressure range

The maximum set pressure has been expanded from the conventional 0.7MPa to 0.8MPa

Compact and light weight

IR1000 width 35mm weight 140g
(previously unavailable small size added)
IR2000 width 50mm weight 300g
(▲ width 14%, weight ▲6% Compared to SMC IR200)
IR3000 width 66mm weight 640g
(▲ width 21%, weight ▲36% Compared to SMC IR400)





Manifolding is possible

Made to order specifications (except series IR2120, IR3000)





Modular body introduced (-X120)

Can be combined with AF (air filter) and AFM (mist separator).



Superior relief flow characteristics

Relief flow has been increased by nearly 5 times (compared to SMC IR201, IR401)



Series Variations

	Model		Basic	Air operated		
Specifications		IR10□0	IR20□0	IR30□0	IR2120	IR3120
	0.2MPa		٠	•	_	_
Maximum	0.4MPa	•	•	•	_	-
set pressure	0.8MPa		•	•	•	•
	Rc(PT) 1/8		-	-	_	_
Port size	Rc(PT) 1/4	—	•	•	•	
FOILSIZE	Rc(PT) 3/8	-	-	•	-	•
	Rc(PT) 1/2	_	_	•	_	

• Available - Not available



Made to Order Specifications

Symbol	Specifications/Content
10-	Clean room specifications
20-	Copper-free specifications
80-	Ozone resistant specifications
–T	For high temperature
-L	For low temperature
-X1	Non-grease specifications
-X465	With digital pressure switch (ISE30)
	Manifold (except series IR2120, IR3000)

SMC



Features 3

SMC

Precision Regulator Series IR1000/2000/3000

Basic

Air operated

Standard Specifications

Mastal		Basic style	Air operated style			
wodei	IR10□0	IR10□0 IR20□0 IR30□0		IR2120	IR3120	
Max. supply pressure			Maximum 1.0MPa			
Min. supply pressure	Set pressure	+0.05MPa (1)	Set pressure+0.1MPa	Set pressure+0.05MPa	Set pressure+0.1MPa	
Set pressure range	IR1000: 0.005 to 0.2 MPa IR1010: 0.01 to 0.4 MPa IR1020: 0.01 to 0.8 MPa	IR2000: 0.005 to 0.2 MPa IR2010: 0.01 to 0.4 MPa IR2020: 0.01 to 0.8 MPa	IR3000: IR3000: 005 to 0.2 MPa 0.01 to 0.2 MPa 010: IR3010: 01 to 0.4 MPa 0.01 to 0.4 MPa 020: IR3020: 01 to 0.8 MPa 0.01 to 0.8 MPa		0.01 to 0.8MPa	
Input signal pressure				0.01 to 0.8MPa	0.01 to 0.8MPa	
Sensitivity			Within 0.2% of full span			
Repeatability			Within 0.5% of full span			
Linearity (3)				Within 1%	of full span	
Air consumption ⁽⁴⁾ (At supply pressure of 1.0 MPa)	4.4 ℓ/min (ANR) or less	4.4 <i>t</i> /min (ANR) or less	11.5 //min (ANR) or less	4.4 <i>t</i> /min (ANR) or less	11.5 ℓ/min (ANR) or less	
Port size	Rc(PT) 1/8	Rc(PT) 1/4	Rc(PT) 1/4, 3/8, 1/2	Rc(PT) 1/4	Rc(PT) 1/4, 3/8, 1/2	
Pressure gauge port			Rc(PT) 1/8 (2 locations)			
Ambient and fluid temperature			– 5 to 60°C (No freezing)			
Weight (kg)	0.14	0.30	0.64	0.35	0.71	

Note 1) With the condition of no flow on the output side. Together with the set pressure, be sure to maintain a minimum differential pressure of 0.05MPa for models IR1000 and IR2000, and 0.1MPa for model IR3000.

Note 2) Applicable only to air operated styles IR2120 and IR3120. The basic style is excepted.

Note 3) Indicates the linearity of the output pressure with respect to the input signal pressure.

Note 4) Air is normally being discharged to the atmosphere.

How to Order



* 4 Manifold specification is available for IR1000 and IR2000.

(Except IR2120 and IR3000)







Series IR1000

Specification Combinations

	•: Standard specifications	D: Con	nbination p	ossible B	lank: Com	bination no	ot possible			
			Applicable model							
	Specifications	Symbol	IR1000 IR1010 IR1020	IR2000 IR2010 IR2020	IR2120	IR3000 IR3010 IR3020	IR3120			
su	Set pressure max. 0.2MPa	0	•	•		•				
atio	Set pressure max. 0.4MPa	1	•	٠		•				
ific	Set pressure max. 0.8MPa	2	•	٠	•		•			
bed	Connection Rc(PT) 1/8	01	•							
lid	Connection Rc(PT) 1/4	02		•	•	•	•			
nda	Connection Rc(PT) 3/8	03				•	•			
Sta	Connection Rc(PT) 1/2	04					•			
Accessories	Bracket	В	0	0	0	0	0			
ALLESSUILES	Pressure gauge		0	0	0	0	0			
(0	Pressure gauge reverse mounted	R	0	0	0	0	0			
ů	Connection NPT1/8	N01	0							
cati	Connection NPT1/4	N02		0	0	0	0			
cifi	Connection NPT3/8	N03				0	0			
d	Connection NPT1/2	N04				0	0			
als	Connection G(PF) 1/8	F01	0							
lion	Connection G(PF) 1/4	F02		0	0	0	0			
Opt	Connection G(PF) 3/8	F03				0	0			
	Connection G(PF) 1/2	F04				0	0			

Modular Products and Accessory Combinations

Description	Applicable model							
Description	IR10□0-□□-X120	IR20_0X120	IR30□0-□□-X120					
1. Air filter	AF20	AF30	AF40					
2. Mist separator	AFM20	AFM30	AFM40					
3. Interface	Y200	Y300	Y400					
4. Interface with bracket	Y200T	Y300T	Y400T					

Note 1) Use the made-to-order product (IR -X120) for modular connections.

The interface and interface with bracket listed above cannot be connected to the standard type. Use a conventional connection interface when connecting the standard type with modular connections.

Note 2) The made-to-order product number (IR - - X120) is for the precision regulator only. For modular connections, please order the applicable products and accessories separately.

<Combination example>



Accessory (Option)/Part No.

Description					Part no.					
Description	IR1000	IR1010	IR1020	IR2000	IR2010	IR2020/2120	IR3000	IR3010	IR3020/3120	
Bracket	P36201023			P36202028			P362030-20*1			
Pressure gauge *2	G33-2-01	G33-4-01	G33-10-01	G43-2-01	G43-4-01	G43-10-01	G43-2-01	G43-4-01	G43-10-01	

*1 A bracket and two mounting screws (M5 x 35)

To mount the bracket, remove two body screws (M5 x 30) on the name plate on the opposite side and replace the attached two bracket mounting screws (M5 x 35).

*2 Accuracy ±3% (Full span)

Construction



Operating Principles (for IR2000)

When the setting knob is turned, the nozzle is closed by the flapper allowing the supply air that flows in from the upstream side to pass through the fixed orifice and to act on diaphragm B as nozzle back pressure, the main valve is pushed down by the generated force and the supply pressure flows out to the downstream side. The air pressure that flows in acts on diaphragm C and while opposing the force generated by diaphragm B, it also acts on diaphragm A opposing the compression force of the setting spring and becomes the set pressure. If the set pressure rises too high, diaphragm A is pushed up, the interval between the flapper and the nozzle widens, the nozzle back pressure drops, the balance of diaphragms B and C is broken, the main valve closes, the exhaust valve opens and the excess pressure from the downstream side is discharged to the atmosphere. In this way fine pressure variations are detected by the nozzle/flapper style pilot mechanism, and precise pressure adjustment is performed.

Replacement Parts

Description

Material

No.



1	Diaphragm assembly	NBR, other	P362010-1	1	P362020-2	1	P362020-2	1	P362020-13	1	P362020-13	1
2	Diaphragm assembly	NBR, other	P362010-2	1	P362020-5	1	P362030-1	1	P362020-5	1	P362030-1	1
3	Diaphragm	NBR, other	_	—	P36202019	1	_	_	P36202019	1	_	_
4	Valve	Stainless steel, NBR	P36201058	1		—	—	—		—	—	—
5	Valve	Stainless steel, NBR	—	—	P36202068#1	—	—	—	P36202068#1	1	—	_
6	Valve	Brass, NBR	_	—	_	—	P36203009#1	1	_	-	P36203009#1	1
7	Valve	Brass, NBR	—	—	_	1	P36203010#1	1	_		P36203010#1	1
8	Damper	NBR, other	P36201021	1	P36202026	2	—	—	P36202026	1	—	—
9	O-ring	H-NBR	ø2.5 x 1.05	3	ø1.42 x 1.52	3	_	—	ø1.42 x 1.52	2	—	—
10	O-ring	NBR	_	—	ø4.5 x 1	1	ø4.5 x 1	1	ø4.5 x 1	3	ø4.5 x 1	1
11	O-ring	NBR	ø10 x 1.3	1	JISB2401P11	—	ø27.8 x 1.5	1	JISB2401P11	1	ø27.8 x 1.5	1
12	O-ring	NBR	—	—		—	JISB2401P5 Note)	1		—	JISB2401P5 Note)	1
13	O-ring	NBR	—	—		—	JISB2401P16 Note)	2	_	_	JISB2401P16 Note)	2
14	Seal (A)	NBR	—	—		—	P36203015	1		—	P36203015	1
15	Seal (B)	NBR	—	—	—	1	P36203016	3	_	—	P36203016	3
16	Fixed throttle	Stainless steel	P36202018	1	P36202018		P36203017	1	P36202018	1	P36203017	1
Repair kit no. (A set of above nos. ① to ⑮.)		nos. (1) to (15.)	KT-IR1000		KT-IR2000		KT-IR3000		KT-IR2120		KT-IR3120	

Note) Use mini-flick type.



Qtv.

Dimensions

IR10□0-01□



IR20 0-02

Pressure gauge (optional)



SMC





0.2 0.3 0.4 0.5 0.6 0.7 0.8 0.9 1.0

Supply pressure P1 (MPa)

Pressure characteristics











Series IR1000/2000/3000 Made to Order Specifications

Contact SMC for detailed dimensions, specifications and delivery times.

Clean Room

10 — Standard model number

Note) Contact SMC if equipped with pressure gauge.

Clean room specifications

Specifications

1

Cleanliness	Class 10000
Bleed port	With M5 fitting (applicable tube O.D. ø6)
EXH port	IR1000/2000: M5 fitting (applicable tube O.D. ø6) IR3000: Rc(PT) 1/2 female thread
Grease	Fluoropolymer grease

2 Copper-free

External and internal copper parts are changed to stainless steel or aluminum.



Note) Contact SMC if equipped with pressure gauge.

Copper-free specifications

3 Ozone Resistant

Fluoro rubber is used for rubber seal materials.

80 — Standard model number

Ozone resistant specifications

4 For High and Low Temperature Environments Standard model number T For high/low temperature environments T For high temperature L For low temperature

Specifications

Symbol	Т	L
Environment	For high temp. environments	For low temp. environments
Ambient temperature	-5 to 100°C (Max. 80°C with pressure gauge)	–30 to 60°C
Rubber material	FKM	Special NBR or silicon rubber

5 Non-Grease

Assembly is performed in an ordinary environment without using grease. However, since parts are not washed, they are not completely oil-free.



Non-grease specifications



Speci	fications							
Ma	de to order p	art no.			−X465 □			
	Set pressure	e range (MPa)		1 to 1				
Pressure	Desolution of set	ting and display (MPa)			0.001			
switch	Power supp	oly voltage	12 to 24 VDC 10%, Ripple (p-p) 10% or less (With reverse connection protection)					
	Current cor	nsumption			40 mA or less			
		How	to O	rder				
Stan	dard mo	del no. ^{Note)}) —	X465				
Note) Ex	cept for sym	bol "G"			─ With digital			
	Note 1) Pleas sepa	se contact SMC rately for details	Г		switch			
0	abou	it the external	<u>•s</u>	Switch	n specifications			
Note 2)	dimer For details or	isions, etc. Lhandling digital	Sym	bol	Output specifications			
11010 2)	pressure swit	ch and specifica-	A	N	PN open collector 1 output			
	tions, refer	tothecatalog	В	PI	NP open collector 1 output			
Note 3)	Digital pre	ssure switch is	С	NPN o	pen collector 1 output + Analog voltage output			
	packed togth	er.	D	NPN o	pen collector 1 output + Analog current output			
2 to 8 st (Please	anifold S tation manifo	pecification	1S (E ors.	xcept ty	rpe IR2120 and series IR3000)			
(1 16436				5 Statio				
IRM	10 —	G–[
	ТТ							
			- 6 S	Set pr	essure and quantity			
					0.2 MPa setting 1 to n pcs.			
			-	1 0	0.4 MPa setting 1 to n pcs.			
				2 0	0.8 MPa setting 1 to n pcs.			
			Ex	ample 1	0.4 MPa setting with 6 stations			
			Exa	ample 2)	IRM10-6G-16 0.2 MPa setting 2 pcs., 0.4 MPa setting 2 pcs., 0.8 MPa setting 1 pc. with 5 stations			
		Stations			IRM20-5G-021221			
		2 2 station	ns d	Acce	essory (Pressure gauge)*			
				Nil	None			
		8 8 station	ns	G	IR1000: G33-□-01 IR2000: G43-□-01			
	Body size 10 IR1	000	:	* Acce	ssory (pressure gauge) is ded, (but not assembled).			
	20 IR2	000 • Thre	ad ty	pe (Thr	read on the manifold base)			
■ M	anifold ty	pe	R	с т				
re	guiator	F	G					
Speci	fications	·						
Statio	ns		2	to 8 sta	ations			
		Common SUP	IR	1000:	1/4, IR2000: 1/2			
Port		Individual OUT	ΓIR	1000:	1/8, IR2000: 1/4			
		Individual EXH	I (Fro	m IR bo	ody)			
Set pr	essure	0.2 M set	IPa, 0 ttings	.4 MPa can be	a and 0.8 MPa e combined.			
Access (Press	sory ure gauge)	G33-□-01	(IR1	000), G	G43-□-01 (IR2000)			
	lote 1) Regul	ators to be manif	folded	are co	unted starting from stations 1			
	on the lote 2) When	e left side with the regulators with	e OUT a diff	l ports i ferent s	in front. set pressure are manifolded,			

te 2) When regulators with a different set pressure are manifolded, viewing OUT ports from front, the low pressure range is installed on the left side and high pressure range is on the right side. In case of the "Example 2)" above mentioned, stations 1 and 2 are of 0.2 MPa setting, stations 3 and 4 are of 0.4 MPa setting, and station 5 is of 0.8 MPa setting.

Note 3) Please consult with SMC when a blanking plate is needed.





Series IR1000/2000/3000 Specific Product Precautions Be sure to read before handling.

Refer to p.0-26 and 0-27 for Safety Instructions and common precautions on the products mentioned in this catalogue.

Air Supply

ACaution

1. If the supply pressure line contains drainage or dirt, etc., the fixed throttle can become clogged leading to malfunction, and therefore, in addition to an air filter (SMC Series AF) be sure to use a mist separator (SMC Series AM, AFM).

Refer to SMC's "Compressed Air Cleaning Systems" catalogue regarding air quality.

2. Never use a lubricator on the supply side of the regulator, as this will positively cause the fixed throttle to become clogged and lead to malfunction. If lubrication is required for terminal devices, connect a lubricator on the output side of the regulator.

Maintenance

Warning

- 1. When the valve guide (refer to construction drawing on p.1.6-6) is to be removed during maintenance, first reduce the set pressure to "0" and completely shut off the supply pressure.
- 2. When a pressure gauge is to be mounted, remove the plug after reducing the set pressure to "0".

Precautions for IR10□0 only

M Warning

1. When remounting the valve guide after removing it for maintenance, use a tightening torque of no more than 0.6Nm. Since the valve guide on this product is made of resin, there is a danger of damage if tightened with a torque exceeding the prescribed value.

Operation

A Caution

- 1. Do not use a precision regulator outside the range of its specifications as this can cause failure. (Refer to specifications.)
- 2. When mounting is performed, make connections while confirming port indications.

Operation

A Caution

- 3. If a directional switching valve (solenoid valve, mechanical valve, etc.) is mounted on the supply side of the regulator and repeatedly switched ON and OFF, wear of the nozzle/flapper section will be accelerated and a discrepancy in the setting value may occur. Therefore, avoid using a directional switching valve on the supply side. In the event a directional switching valve will be used, install it on the output side of the regulator.
- 4. Air is normally discharged from the bleed port (the hole on the side of the body's midsection). This is a necessary consumption of air based on the construction of the precision regulator, and is not an abnormality.
- 5. Be sure to tighten the lock nut after pressure adjustment.

Precautions for IR30 0, IR3120 only

A Caution

- 1. The supply pressure is relatively high (approx. 0.5MPa or more), the set pressure is low (approx. 0.1MPa or less), and when operated with the output side released to the atmosphere, there may be pulsations in the setting side pressure. In this kind of situation, operate with the supply pressure reduced as much as possible, or increase the set pressure somewhat and restrict the output line (add and adjust a stop valve, etc.).
- 2. The capacity of the output side is large, and when used for the purpose of a relief function, the exhaust sound will be loud when being relieved. Therefore, operate with a silencer (SMC Series AN) mounted on the exhaust port (EXH port). The connection is Rc(PT) 1/2.

Precautions for IR2120, IR3120 (air operated style) only

\land Caution

- 1. Since the output of types IR2120 and IR3120 is the same pressure as the input signal pressure, select a type of regulator (general purpose or precision type) for input signal pressure adjustment according to the application.
- 2. The screw on the topmost section is a zero point adjustment screw which is locked at the factory and requires no adjustment for operation.



Series IR1000/2000/3000 Precision Regulator Precautions

Refer to p.0-26 and 0-27 for Safety Instructions and common precautions on the products mentioned in this catalogue.

Piping

Warning

1. Screw piping together with the recommended proper torque while holding the side with female threads.

Looseness or faulty sealing will occur if tightening torque is insufficient, while thread damage will result if the torque is excessive. Furthermore, if the side with the female threads is not held while tightening, excessive force will be applied directly to piping brackets, etc. causing damage or other problems.

F



2. Do not allow twisting or bending moment to be applied other than the weight of the equipment itself.

Provide separate support for external piping, as damage may otherwise occur. $\hfill {\hfill {\hill {\hill {\hfill {\hill {\h$



3. Since excessive moment loads and the propagation of vibrations, etc. can easily result from inflexible piping made of steel, etc., avoid these problems by using flexible tubing for intermediate connections.

Piping

A Caution

1. Preparation before piping

Before piping is connected, it should be thoroughly blown out with air (flushing) or washed to remove cutting chips, cutting oil and other debris from inside the pipe.

2. Wrapping of pipe tape

When connecting pipes and fittings, etc., be sure that cutting chips from the pipe threads and sealing material do not get inside.

Further, when pipe tape is used, leave 1.5 to 2 thread ridges exposed at the end of the pipe/fitting.



Operating Environment

Warning

- 1. Do not operate in locations having an atmosphere of corrosive gases, chemicals, sea water, water or steam, or where there will be contact with the same.
- 2. Do not operate in locations where vibration or impact occurs.
- 3. In locations which receive direct sunlight, provide a protective cover, etc.
- 4. In locations near heat sources, block off any radiated heat.
- 5. In locations where there is contact with spatter from water, oil or solder, etc., implement suitable protective measures.

Air Supply

A Warning

- 1. These products are designed for use with compressed air. Contact SMC if any other fluid will be used.
- 2. Do not use compressed air which includes chemicals, synthetic oils containing organic solvents, salt, or corrosive gases, etc., as this can cause damage or malfunction.
- 3. If drainage is not removed from air filters and mist separators, it can flow out to the downstream side and lead to the malfunction of pneumatic equipment.

In cases where the management of drainage removal will be difficult, the use of filters with auto drains is recommended.

▲ Safety Instructions

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "**Caution**," "**Warning**" or "**Danger**." They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC)^{*1}, and other safety regulations.



Safety Instructions | Be sure to read "Handling Precautions for SMC Products" (M-E03-3) before using.

SMC Corporation (Europe)

Austria	2 +43 (0)2262622800	www.smc.at	office@smc.at	Lithuania	2 +370 5 2308118	www.smclt.lt	info@smclt.lt
Belgium	2 +32 (0)33551464	www.smcpneumatics.be	info@smcpneumatics.be	Netherlands	2 +31 (0)205318888	www.smcpneumatics.nl	info@smcpneumatics.nl
Bulgaria	2 +359 (0)2807670	www.smc.bg	office@smc.bg	Norway	2 +47 67129020	www.smc-norge.no	post@smc-norge.no
Croatia	2 +385 (0)13707288	www.smc.hr	office@smc.hr	Poland	2 +48 (0)222119616	www.smc.pl	office@smc.pl
Czech Republic	2 +420 541424611	www.smc.cz	office@smc.cz	Portugal	2 +351 226166570	www.smc.eu	postpt@smc.smces.es
Denmark	2 +45 70252900	www.smcdk.com	smc@smcdk.com	Romania	2 +40 213205111	www.smcromania.ro	smcromania@smcromania.ro
Estonia	2 +372 6510370	www.smcpneumatics.ee	smc@smcpneumatics.ee	Russia	2 +7 8127185445	www.smc-pneumatik.ru	info@smc-pneumatik.ru
Finland	🕿 +358 207513513	www.smc.fi	smcfi@smc.fi	Slovakia	2 +421 (0)413213212	www.smc.sk	office@smc.sk
France	🕿 +33 (0)164761000	www.smc-france.fr	promotion@smc-france.fr	Slovenia	2 +386 (0)73885412	www.smc.si	office@smc.si
Germany	2 +49 (0)61034020	www.smc.de	info@smc.de	Spain	2 +34 902184100	www.smc.eu	post@smc.smces.es
Greece	2 +30 210 2717265	www.smchellas.gr	sales@smchellas.gr	Sweden	2 +46 (0)86031200	www.smc.nu	post@smc.nu
Hungary	2 +36 23511390	www.smc.hu	office@smc.hu	Switzerland	2 +41 (0)523963131	www.smc.ch	info@smc.ch
Ireland	2 +353 (0)14039000	www.smcpneumatics.ie	sales@smcpneumatics.ie	Turkev	🕿 +90 212 489 0 440	www.smcpnomatik.com.tr	info@smcpnomatik.com.tr
Italy	2 +39 0292711	www.smcitalia.it	mailbox@smcitalia.it	UK	2 +44 (0)845 121 5122	www.smcpneumatics.co.uk	sales@smcpneumatics.co.uk
Latvia	2 +371 67817700	www.smclv.lv	info@smclv.lv				

 SMC CORPORATION
 Akihabara UDX 15F, 4-14-1, Sotokanda, Chiyoda-ku, Tokyo 101-0021, JAPAN Phone: 03-5207-8249
 FAX: 03-5298-5362

 1st printing SR printing SR 00
 Printed in Spain
 Specifications are subject to change without prior notice and any obligation on the part of the manufacturer.