

### **DIN Fine-fit Connectors**

XC5

# International DIN standards; Solderless Connection Series (Fine Fit)

- Backplane systems can be designed with ease with XC5 Connectors as conforming with DIN standards.
- Using unique W-shaped pins, these Connectors prevent contacts from being bent or falling out. Ensures highly reliable connections.
- Less damage to the through-holes in circuit boards.
- Uses highly-reliable Twin-contact Sockets.
- A special Press-fit Tool is available.
- See the "Standards certification / conformity list" for information on conformity to certification standards.

**RoHS Compliant** 


### ■ Ratings and Characteristics

Rated current	2 A
Rated voltage	300 VAC
Contact resistance	20 mΩ max. (at 20 mV, 100 mA max.)
Insulation resistance	$10^6$ M $\Omega$ min. (at 100 VDC)
Dielectric strength	1,000 VAC for 1 min (leakage current: 1 mA min.)
Total insertion force	0.59 N max. per contact
Removal force	0.15 N min. (with test gauge, t = 0.56 mm)
Insertion durability	200 times
Ambient operating temperature	-55 to 125°C (with no icing at low temperature)

#### **■** Materials and Finish

Туре		Plugs	Sockets
Housings		Fiber-glass reinforced PBT resin (UL94 V-0)/gray	
Contacts (See note.)	Mating end	Copper alloy/nickel base, 0.4-µm gold plating	
	Fine fit	Copper alloy/nickel base, gold flash plating	
	Terminal	Copper alloy/nickel plating (See note.)	base, 0.15-μm gold

**Note:** For non-standard plating specifications, contact your OMRON representative.



#### ■ Applicable Wrap Post Wire Sizes

AWG30, AWG28, AWG26, or AWG24 (Solid wire: 0.25 to 0.51 mm dia.)

#### ■ Wrap Post Length

3 wires for the 13-mm contacts 4 wires for the 17-mm contacts

#### ■ Ratings for Fine-fit Connectors

Rated current	2 A
Contact resistance	5 mΩ max. (at 20 mV, 100 mA max.)
Pressure input	196 N max. per contact
Holding force	44.1 N min.
Unit torque durability	0.022 N-m min.
Vibration	At 10 to 2,000 Hz, 1.52-mm amplitude, or 147 m/s $^2$ will not interrupt current for more than 1 $\mu$ sec.
Shock	At 980 m/s <sup>2</sup> , will not break current for more than 1 μ sec.


#### **■** Applicable Fine-fit Boards

- Width 1.6 to 3.2 mm
- Through-hole diameter 1.0  $\pm 0.08$  mm (Drill diameter 1.15  $\pm 0.05$  mm)


Plating: Copper 25 mm min., or solder 5 mm min. on a copper base at least 25 mm thick.

• Pitch error: ±0.03 mm max.

# XC5B Double-row Sockets, DIN B-type, Fine-fit



### **■** Ordering Information



64

100

94.8

140.5

85.0

130.7

78.74

124.46

90.00

135.72

82.9


128.7

6, 13, 20, 27

10, 20, 31, 41

# XC5E Double-row Plugs, DIN Q-type, Fine-fit

■ Dimensions (unit: mm)




#### **Dimensions**

No. of			Coding Key				
contacts	Α	В	С	D	E	F	positions (contact No.)
32	54.2	47.4	38.10	44.6	43.3	49.36	5, 12
64	94.8	88.0	78.74	85.2	83.9	90.00	6, 13, 20, 27
100	140.5	133.7	124.46	130.9	129.7	135.72	10, 20, 31, 41

## **■** Ordering Information

Appear- ance					
No. of Terminal type					
contacts	Straight terminals, 4 mm	Straight terminals, 13 mm	Straight terminals, 17 mm		
32	XC5E-322P-1140	XC5E-322P-1131	XC5E-322P-1132		
64	XC5E-642P-1140	XC5E-642P-1131	XC5E-642P-1132		

# XC5D Triple-row Sockets, DIN C-type, Fine-fit




### **■** Ordering Information

Appear- ance				
No. of	Terminal type			
contacts	Straight terminals, 4 mm	Straight terminals, 13 mm	Straight terminals, 17 mm	
48	XC5D-482P-1140	XC5D-482P-1131	XC5D-482P-1132	
64*	XC5D-642P-1140	XC5D-642P-1131	XC5D-642P-1132	
96	XC5D-962P-1140	XC5D-962P-1131	XC5D-962P-1132	

<sup>\*</sup>Has no center row (row b).

## XC5G Triple-row Plugs, DIN R-type, Fine-fit



#### **Dimensions**

No. of	Dimensions (mm)					Coding Key positions	
contacts	Α	В	С	D	Е	F	(contact No.)
48	54.2	47.4	38.10	44.6	43.3	49.36	5, 12
64*	94.8	88.0	78.74	85.2	83.9	90.00	6, 13, 20, 27
96	94.8	88.0	78.74	85.2	83.9	90.00	6, 13, 20, 27

<sup>\*</sup>Has no center row (row b).

## **■** Ordering Information


Appear- ance				
No. of	Terminal type			
contacts	Straight terminals, 4 mm	Straight terminals, 13 mm	Straight terminals, 17 mm	
48	XC5G-482P-1140	XC5G-482P-1131	XC5G-482P-1132	
64*	XC5G-642P-1140	XC5G-642P-1131	XC5G-642P-1132	
96	XC5G-962P-1140	XC5G-962P-1131	XC5G-962P-1132	

<sup>\*</sup>Has no center row (row b).

### ■ XC5 Accessories

#### Press-fit Tool (XY2D-1005)

- Hand-operated tool designed especially for mounting Fine-fit Connectors to a board.
- Hand-operated for ease and safety.
- The Press-fit Tool User's Manual must be ordered separately.



#### **Specifications**


Applicable Connectors	XC5□-□□□P Fine-fit
Max. pressure	2 t
Stroke (max.)	8 mm (handle) 283 mm (handle wheel)
Weight	80 kg
Base area	500 mm × 530 mm


#### Model

Model	XY2D-1005

#### **Contact Repair Tools**

- The tool works on top of the Connector.
- This tool is used for correcting mistakes made with the Press-fit Tool. (plugs only)
- For details on use, see the Fine-fit Connector Press-fit Tool User's Manual. The User's manual must be ordered separately.





For sockets

#### For Plugs


Rows	No. of contacts	Model
Double rows	32	XY2D-1007
(XC5E)	64	XY2D-1006
Triple rows	48	XY2D-1009
(XČ5G)	96 (64)	XY2D-1008

#### **For Sockets**

Rows	No. of contacts	Model
Double rows	32	XY2D-1011
(XC5B)	64	XY2D-1010
Triple rows	48	XY2D-1013
(XC5D)	96 (64)	XY2D-1012

#### **Support Block and Plungers**

- The Support Block and Plungers (2) are set on top of the base board.
- The Support Block is used to protect the fine-fit pins while the Press-fit Tool is being used.
- The Plunger is inserted into the mounting holes. It functions as a positioner for the Connector and cushions the Contact Repair Tool.





#### **Support Blocks**

Rows	No. of contacts	Model
Double rows	64	XY2D-1014
Triple rows	96	XY2D-1015


Note: Cut the XY2D-1014 when using Doublerow Connectors with 100 or 32 contacts. Cut the XY2D-1015 when using Triple-row Connectors with 100 or 32 contacts (no center row).

#### **Plungers**

Applicable board thickness	Model	
1.6 to 3.2 mm	XY2D-1017	

## Setting the Repair Tool, Support Block, and Plunger

- Base board is not supplied by OMRON.
- The base board including the Support Block and Plunger are collectively called the Support Assembly.
- Place the circuit board on top of the Support Assembly and place the whole thing on the Press-fit Tool.
- Insert the Fine-fit Connectors into the board one at a time by moving the Support Assembly left and right.



#### **Accessories for Backplane Systems**

#### Daughter board side **Rear Side**

Spacer (available in market) Nut (available in market) Ð Backplane Backplane (mother board) housing Fine-fit Connector Backplane Connector Note: When ordering the following Housings, order according to the number per box.

## **Double-row Type**

No. of contacts	Model
32	XC5E-32
64	XC5E-64

#### **Triple-row Type**

No. of contacts	Model
48	XC5G-48
96 (64)	XC5G-96

#### Spacer

When using the housing, use the correct spacer for the board as shown below.

Terminal length	2.4-mm board	3.2-mm board	1.6-mm board
13 mm	0.5 mm	(See note.)	1.3 mm
17 mm	4.5 mm	3.7 mm	5.3 mm

Note: For wrap terminals only.

#### Backplane Housings (for DIN Connectors) Backplane Housing (MIL Flat, Double-row Type)

No. of contacts	Model	
64	XG4A-64A	

Note: The housing can be used only when the board thickness is 2.4 mm. It can be used only when the length of the DIN Fine-fit Connector is 17 mm.



#### **Precautions**

#### **Correct Use**

#### **Basic Mating Dimensions**

The basic mating dimensions conform to those of the XC5. See page 11 of DIN Twin-contact Connectors XC5.

#### **Press-fit Tools and Press-fit Precautions**

OMRON provides manuals for Press-fit Tools and precautions. Contact your OMRON representative to request copies.

#### **Through-hole Diameters**

Holes with 1.0 mm dia. are required by the above Fine-fit Connector.

#### Storage

If the XG4A is stored with the lock half open, the resin parts may deteriorate, causing the lock to feel loose.

When a Connector is not used, close or open the lock completely before you store the Connector.


#### **Mounting Prohibited area**

Top jig side: Mounting of parts is prohibited in the area of the max. outer shape + 1 mm.


Bottom jig: Mounting of parts is prohibited in an area of the support block max. outer shape and plunger max. outer shape.

#### Top jig (Unit: mm)

Double rows




#### Triple rows




#### Support Blocks (unit: mm)

Double rows



#### Triple rows



#### Plungers (unit: mm)



Note: An outline drawing of the 64-pin and 96-pin top jigs and support blocks is shown as a sample. For parts with other number of pins, contact your OMRON sales representative.

Please check each region's Terms & Conditions by region website.

OMRON Corporation
Electronic and Mechanical Components Company

#### **Regional Contact**

Americas

https://www.components.omron.com/

Asia-Pacific

https://ecb.omron.com.sg/

Korea

https://www.omron-ecb.co.kr/

Europe

http://components.omron.eu/

China

https://www.ecb.omron.com.cn/

Japan

https://www.omron.co.jp/ecb/